



Press lever to spring lamps forward to be able to change lamp.

230v NC neon.