



Setting Instructions

To start, clear whatever is in clock, press reset with a pen or pencil.

2. Set clock. Press and hold clock button.
 - i. Press day button to set day, shows on top edge.
 - ii. Press hour button to set hour.
 - iii. Press minutes button to set minutes.
 - iv. Release clock button.

Pull out clear plastic strip to start clock.

To Set On and Offs:

1. Press and release timer button.
 - i. Set days or day to be on (all week)(individual days)(Monday-Friday)(Saturday and Sunday)
 - ii. Set hour – set minutes.
 - iii. Re-press timer once, first off will show.
 - iv. Set off time.

Eight on/offs are available.

